

MED1-4013

Fast-cure silicone adhesive

DESCRIPTION

- Two-part, translucent, thixotropic, high tear strength silicone system
- Cures at room temperature and will cure rapidly with the application of heat in an oven, or by a heat gun or lamp
- Many bonding applications do not require the use of a silicone primer for suitable adhesion
- Does not require atmospheric moisture to cure
- No curing byproducts such as acetic acid or methyl alcohol
- Consistency allows product to be supplied in easy-to-use, airless side-by-side kits that eliminate mixing and deairing difficulties
- Work time of ~ 15 minutes
- Cures in less than 24 hours at room temperature
- Cures via addition-cure chemistry
- 1:1 Mix Ratio (Part A: Part B)

APPLICATION

- Well suited for use as an adhesive for bonding and sealing silicone materials
- For applications requiring the bonding of silicone to metals, urethanes and various other substrates
- For rapid production or prototyping due to a rapid cure

NuSil™ MED1-4013 shall not be considered for use in human implantation for a period of greater than 29 days.

PROPERTIES

Typical Properties	Average Result	Standard	NT-TM
Uncured:			
Appearance	Translucent	ASTM D2090	002
Viscosity, Part A	80,000 cP (80,000 mPas)	ASTM D1084, D2196	001
Work Time	15 minutes	-	008
Cured: 24 hours minimum at ambient temperature and humidity			
Specific Gravity	1.11	ASTM D792	003

Typical Properties	Average Result	Standard	NT-TM
Durometer, Type A	20	ASTM D2240	006
Tensile Strength	1,015 psi (7.0 MPa)	ASTM D412	007
Elongation	760%	ASTM D412	007
Tear Strength	130 ppi (22.9 kN/m)	ASTM D624	009
Tissue Culture (Cytotoxicity Testing)	Pass	USP <87> ISO 10993-5	061
Elemental Analysis of Trace Metals	Pass	ASTM E305	131

The above properties are tested on a lot-to-lot basis. Do not use as a basis for preparing specifications. Please [contact](#) NuSil Technology for assistance and recommendations in establishing particular specifications.

INSTRUCTIONS FOR USE

Mixing

Combine Part A and Part B in a 1:1 mix ratio prior to use. Airless mixing, metering, or dispensing equipment is recommended for production operations. If mixing by hand, take care to minimize air entrapment.

Vacuum Deaeration

Remove air entrapped during mixing by common vacuum deaeration procedure, observing all applicable safety precautions. Slowly apply full vacuum to a suitable container of at least four times the volume of material being de-aired. Hold vacuum until bulk deaeration is complete.

Substrate Considerations

Cures in contact with most materials common to biomedical assemblies. Exceptions include: sulfur-cured organic rubbers, latex, chlorinated rubbers, some RTV silicones and unreacted residues of some curing agents.

Surface Preparation

Thoroughly clean surfaces being bonded or built-up with silicone adhesive using a non-oily cleaner or mild soap to remove any surface contaminants. Do not use synthetic detergents or oil-based soaps, as they may be absorbed and subsequently leach out. Rinse first with hot water, followed by a thorough rinse using distilled water. Use compatible degreasers to clean metal surfaces.

Bonding Applications

Spread a layer of silicone adhesive on one of the surfaces. Squeeze both surfaces together to bond. Apply sufficient pressure to ensure full contact without forcing the silicone adhesive from between the pieces.

Packaging

50 ml SxS Kit
200 ml SxS Kit
400 ml SxS Kit
2 Pint Kit (910 g)
2 Gallon Kit (7.28 kg)
10 Gallon Kit (36.4 kg)

Warranty

12 Months

Note: Some bonding applications may require the use of a primer. NuSil Technology's MED1-161 is recommended. For more information on primer selection, visit www.nusil.com and review [Choosing a Silicone Primer/Adhesive System](#).

FDA MASTER FILE

A Master File for MED1-4013 has been filed with the U.S. Food and Drug Administration. Customers interested in authorization to reference the Master File must [contact](#) NuSil Technology.

REACH COMPLIANCE

Please [contact](#) NuSil Technology's Regulatory Compliance department with any questions or for further assistance.

SPECIFICATIONS

Do not use the properties shown in this technical profile as a basis for preparing specifications. Please [contact](#) NuSil Technology for assistance and recommendations in establishing particular specifications.

WARRANTY INFORMATION

The warranty period provided by NuSil Technology LLC (hereinafter "NuSil Technology") is 12 months from the date of shipment when stored below 40°C in original unopened containers. Unless NuSil Technology provides a specific written warranty of fitness for a particular use, NuSil Technology's sole warranty is that the product will meet NuSil Technology's then current specification. NuSil Technology specifically disclaims all other expressed or implied warranties, including, but not limited to, warranties of merchantability and fitness for use. The exclusive remedy and NuSil Technology's sole liability for breach of warranty is limited to refund of purchase price or replacement of any product shown to be other than as warranted. NuSil Technology expressly disclaims any liability for incidental or consequential damages.

WARNINGS ABOUT PRODUCT SAFETY

NuSil Technology believes, to the best of its knowledge, that the information and data contained herein are accurate and reliable. The user is responsible to determine the material's suitability and safety of use. NuSil Technology cannot know each application's specific requirements and hereby notifies the user that it has not tested or determined this material's

suitability or safety for use in any application. The user is responsible to adequately test and determine the safety and suitability for their application and NuSil Technology makes no warranty concerning fitness for any use or purpose. NuSil Technology has completed no testing to establish safety of use in any medical application.

NuSil Technology has tested this material only to determine if the product meets the applicable specifications. (Please [contact](#) NuSil Technology for assistance and recommendations when establishing specifications.) When considering the use of NuSil Technology products in a particular application, review the latest Material Safety Data Sheet and [contact](#) NuSil Technology with any questions about product safety information.

Do not use any chemical in a food, drug, cosmetic, or medical application or process until having determined the safety and legality of the use. The user is responsible to meet the requirements of the U.S. Food and Drug Administration (FDA) and any other regulatory agencies. Before handling any other materials mentioned in the text, the user is advised to obtain available product safety information and take the necessary steps to ensure safety of use.

PATENT / INTELLECTUAL PROPERTY WARNING

NuSil Technology disclaims any expressed or implied warranty against the infringement of any domestic or international patent/intellectual property right. NuSil Technology does not warrant the use or sale of the products described herein will not infringe the claims of any domestic or international patent/intellectual property right covering the product itself, its use in combination with other products, or its use in the operation of any process.